WWW.PREVENT-SYSTEMS.COM

DATASHEET

**Prev3con**AUTOMATIC LOW PRESSURE
WATER MIST NOZZLE

## PREVENT SYSTEMS WHEN SAFETY IS TAKEN SERIOUSLY







## Prev3con

## AUTOMATIC LOW PRESSURE WATER MIST NOZZLE

## Part 1

#### **General description**

The Prev3con is designed and successfully tested for fixed fire protection systems in Residential and Domestic applications, according to BS 8458:2015 and NS- INSTA 900-3. This would include protection of homes, care institutions, apartment buildings, and sleeping areas in hospitals, hotels etc.





#### **Technical Data**

Minimum operating pressure5.2 barMaximum operating pressure16 barMaximum standby pressure12 barK-factor14Minimum flow rate32 lpm

Nozzle material Brass (CW602N)

Thread size 1/2" straight BSP, NPT
Strainer 0.24mm Stainless steel

**Thermally actuated bulb** Fast response 3 x 16, RTI 36 (ms)<sup>1/2</sup>

**Release temp.** 57°C, 68°C **Nozzle position** Pendant

**Nozzle size** Total length = 32mm, Max. diameter = 39mm

Length under finished ceiling = 8.5mm

**Piping (non-corrosive)** Stainless steel, PrevPex, RedPipe, CPVC,

subject to approval in each case.

SIN Prev3con

\*The jockey-pump shall be set to maintain the standby pressure in the system, up to a maximum of 12 bar.



## Prev3con

## AUTOMATISKE LAVTRYKK VANNTÅKE DYSER

#### Part 1



The nozzles must be handled carefully before, -under and -after installation. Nozzles that are damaged in any way, must be replaced. Follow these installation steps:

- The temperature bulb shall be checked for damage prior to installing the nozzle into the nozzle fitting. A small air bubble in the bulb shall easily slide back and forth when tilting the nozzle. There shall be no loss of liquid or cracks in the bulb.
- · Apply appropriate sealant to the nozzle threading before hand-tightening it into the nozzle fitting.
- Use the installation tool on a socket wrench and carefully tighten the nozzle, ensuring that one of the four marks on the installation plate face a corner of the room (see sketches below).
- The nozzle's 6-sided installation plate shall be flush with the ceiling, but not over-tightened.
- Finally place the magnetic rosette onto the installation plate. The rosette can easily be removed for
  painting or plastering, without touching the nozzle.





#### Operation

During a fire, the fluid in the fast response thermally actuated glass bulb will expand and shatter. The nozzle valve would then drop down, allowing the water to flow through the nozzle and suppress or extinguish the fire.

## Maintenance

The nozzles shall be handled carefully before, -under and -after installation. Nozzles that are damaged in any way, shall be replaced. The nozzles shall not be painted, coated or otherwise altered after leaving the factory.

## Notes

For a full description, please refer to the Design, Installation, Operation and Maintenance manual (DIOM). A full training course is offered for the appropriate design, installation, operation and maintenance of Prevent Systems low-pressure water mist automatic fire suppression systems. Prevent Systems is ISO 9001 certified, and the water mist nozzles are produced and tested to stringent in-house quality standards.



## Prev3con

## AUTOMATIC LOW PRESSURE WATER MIST NOZZLE

#### Part 2

The Prev3con is designed and successfully tested for fixed fire protection systems in Residential and Domestic applications, according to BS DD8458-1:2010 and NS- INSTA 900-3. This would include protection of homes, care institutions, apartment buildings, and sleeping areas in hospitals, hotels etc.

## Design

Each system shall be hydraulically designed according to the minimum water flows and water pressure, as specified in the Technical Data section, and the maximum allowable coverage area for the nozzles, as described below. The system shall meet the design requirements specified by the Authorities Having Jurisdiction (AHJ).

**Application** Residential and domestic

Max coverage area  $4m \times 4m = 16 \text{ m}^2$ 

Spacing between nozzles Maximum 4m, minimum 2m

Distance to wall\* Maximum 2m, minimum 0.1m

**Distance to ceiling** Flush with ceiling – use Prev3exp for exposed pipe

Maximum ceiling height\*\* 3.5m

**Piping (non-corrosive)** Stainless steel, PrevPex, RedPipe, CPVC,

subject to approval in each case.

Fire test standard BS 8458:2015 and NS- INSTA 900-3

\* The maximum distance in one direction can be exceeded by up to 20 % if the other direction is reduced correspondingly, so that the maximum coverage area for the nozzle is not exceeded.

\*\*The Prev3con nozzle can be installed up to a 3.5m ceiling height. Ceiling heights exceeding 3.5m are subject to approval in each case. (The Prev2exp or the Prev5exp are both options for higher ceilings.)

Section 5 of the DIOM describes in detail the design requirements and limitations, nozzle spacing, positioning with respect to obstacles, ceiling slopes, etc. Section 6 covers hydraulic calculations.



## LIMITED WARRANTY

# 5-YEAR LIMITED PRODUCT WARRANTY ON PREVENT SYSTEMS LOW PRESSURE WATER MIST NOZZLES



#### The warranty shall cover:

This warranty applies to the full extent permitted by law. The warranty applies to the original buyer for 5 years from date of purchase against defects in material or production workmanship, and only if the nozzles are paid for in full, installed and maintained pursuant to Prevent Systems directions for installation and maintenance.

Nozzles found to be defective shall be repaired or replaced by Prevent Systems. Prevent Systems will not cover any costs or obligations in connection with the sale, repair, or replacement without prior written agreement.

The warranty rights shall follow the building and shall apply to the person who can document that he/she owns the building.

### The warranty does not cover:

The warranty does not cover incorrect handling, storage, design or installation of the water mist nozzles. Prevent Systems shall not be liable for any indirect or consequential damages, including labor charges, and the liability shall not exceed the amount of the sales price.

#### Notification of claim:

Notification of claims which falls under this warranty shall be reported to Prevent Systems in writing without delay, so that immediate action to remedy the issue can be taken.

The rights of this warranty is a supplement to the additional rights of the buyer on the basis of the legislation.

## Contact

For further information please contact us at post@prevent-systems.no or via our web-site www.prevent-systems.com

Fåberggaten 126 N-2615, Lillehammer Norway

